



Power Availability Chart

NEVO FX-560SP (-/-) 70mm



SP / CY	0.00	-0.25	-0.50	-0.75	-1.00	-1.25	-1.50	-1.75	-2.00	-2.25	-2.50	-2.75	-3.00	-3.50	-4.00
0.00															
-0.25															
-0.50															
-0.75															
-1.00															
-1.25															
-1.50															
-1.75															
-2.00															
-2.25															
-2.50															
-2.75															
-3.00															
-3.25															
-3.50															
-3.75															
-4.00															
-4.25															
-4.50															
-4.75															
-5.00															
-5.25															
-5.50															
-5.75															
-6.00															
-6.25															
-6.50															
-6.75															
-7.00															
-7.25															
-7.50															
-7.75															
-8.00															
-8.25															
-8.50															
-8.75															
-9.00															
-9.25															
-9.50															
-9.75															
-10.00															



Power Availability Chart

NEVO FX-560SP (+/-) 65mm



SP / CY	0.00	-0.25	-0.50	-0.75	-1.00	-1.25	-1.50	-1.75	-2.00
+0.25									
+0.50									
+0.75									
+1.00									
+1.25									
+1.50									
+1.75									
+2.00									
+2.25									
+2.50									
+2.75									
+3.00									
+3.25									
+3.50									
+3.75									
+4.00									